

GT 100 Pump: Oils & petroleum-based liquids

Listed substances are suitable for use with **GT 100** pumps. Before use, read and observe all warnings and cautions below, and in the *GoatThroat Instruction Manual*. To check for the most recently updated listings, please visit our web site at www.GoatThroat.com.

ACB - 30	Butter	Developing Fluids (photo)	Kerosene (1)
Acetamide	Butyl Amine	Dextron	Lactic Acid
Acetylene (1)	Butyl Carbitol	Diacetone (1)	Lard
AGRITOX	Butylene	Diethylene Glycol	LARVIN 375
Aluminium Acetate	Calcium Acetate	Diisobutyl Ketone	Lead Acetate
Aluminium Bromide	Calcium Bisulfide	Diisobutylene	Lead Nitrate
Aluminium Chloride 20%	Calcium Carbonate (Chalk)	Distilled Water	LEAFEX
Aluminium Fluoride 20%	Calcium Chloride (Brine)	DIURON FLOWABLE	LEGUMEX
Aluminium Nitrate	Calcium Cyanide	DODINE FLOWABLE	Light Grease
Aluminium Salts	Calcium Hydroxide	DTE Light oil	Lime Bleach
Aluminium Sulfate 10%	Calcium Nitrate	ESI-CRYL 11	Lubricating Oils (Petroleum)
Alums- NH ₃ -Cr-K	Calcium Phosphate	Ethane	Lye
Ammonium Carbonate 10%	Calcium Salts	Ethanol	Magnesium Chloride
Ammonium Dibasic	Calcium Silicate	Ethanol 95%	Magnesium Hydroxide
Ammonium Monobasic	Calcium Sulfide	Ethanolamine (1)	Magnesium Salts
Ammonium Nitrate	Calcium Sulphite	ETHREL (2)	Magnesium Sulfate
Ammonium Phosphate (Di, Tri, Mono)	CALIBRATION FLUID 4113	Ethyl Cellosolve	Magnesium Sulphite
Ammonium Salts	Cane Sugar Liquors	Ethyl Silicate	MALATHION
Ammonium Sulfate	Carbitol (2)	Ethyl Cyclopentane	Malic Acid
Ammonium Sulphide	Carbon Dioxide	Ethylene Diamine	MCPA
Amyl-Borate	Carbon Monoxide	Ethylene Glycol	MCPA 375 SALT
Amyl-Chloride	Carbonic Acid	Fatty Acids	MCPA LVE 500
Animal Fats	Castor Oil	Ferric Chloride	Mercuric Chloride (Dilute Solu.)
Arsenic Acid	Cetane	Ferric Nitrate	Methane
ASE-60	China Wood Oil	FLUOMETURON FLOWABLE	Methyl Cellosolve
Automatic Transmission Fluid	Chrome Alum	FOLICUR 250 EW	Methyl Ether
Baking Soda	Chrome Plating Solutions	FOLICUR 430 SC	Milk
Barium Chloride	Chromic Oxide.88 WT.%, aqueous	Fuel Oil	Mineral Oil
Barium Hydroxide	Citric Acid	Gallic Acid	Monoethanolamine (1)
Barium Salts	Cobalt Chloride	Gelatin	Monovinyl Acetylene
BAYTAN C Flowable seed dressing	Coconut Oil	Glucose	Neatsfoot Oil
Beet Sugar Liquors	Cod Liver Oil	Glycerin	Neon
Black Sulphate Liquors	Coffee	Glycols	Nickel Acetate
BLAZER	CONFIDOR 350 SC	Green Sulfate Liquor	Nickel Chloride
Bordeaux Mixture (Copper Sulfate Salt)	COOLANOL	GUSATHION 200 SC	Nickel Sulfate
Boric Acid	Copper Chloride	Heavy Water	N-Octane
Boron Fluids	Copper Cyanide	Hexyl Alcohol	N-Pentane
Brine	Copper Salts	Hydraulic Oils (Petroleum) (1)	Octadecane
BRODAL	Copper Sulfate 5% Solution	Hydrazine	Octyl-Alcohol
BRYTOFA	Corn Oil	Hydrocyanic Acid	O-Dichlorobenzene (1)
BUGMASTER FLO	Cottonseed Oil	Hydroquinone (2)	Olive Oil
Bunker Oil	Creosote, Coal Tar	Isooctane	OMALA OIL 220
Butane (LPG) (1)	Cutting Oil	Isododecane	Oxalic Acid (Cold)
	Denatured Alcohol	Isopropanol	OXAMIN LO
	Detergents	Isopropyl Alcohol	Palmitic Acid
		Isopropyl Ether (2)	PANOCTINE

List continues on next page →

(1) Test pump before use

(2) Wash pump after use

WARNING: Do not use with the following substances:
Hydrofluoric Acid • Jaguar • Morpholine • Tigrex

* CAPITAL LETTERS denote brand names. All brand name trademarks and registered trademarks are the property of their respective corporations.

**Westcott
Distribution**

184 W. 10th St., New York, NY 10014
(646) 486-3636 • Fax (212) 243-6070

GT100-PCG-1002A

➤ **GT 100 (red pump with Nitrile seal)**

GT 200 (blue pump with EPDM seal)

GT 200S (blue pump with Santoprene seal)

GT 300 (green pump with Viton seal)

Document date: **7 October 2002**

GT 100 Pump: Oils & petroleum-based liquids

Listed substances are suitable for use with **GT 100** pumps. Before use, read and observe all warnings and cautions below, and in the *GoatThroat Instruction Manual*. To check for the most recently updated listings, please visit our web site at www.GoatThroat.com.

← *List continued from previous page*

Paraffin Oil	Potassium Nitrate	Sodium Bisulfite	Stannous Chloride
Peanut Oil	Potassium Salts	Sodium Borate	Sucrose Solution
Pentane 2 Methyl	Potassium Sulfate	Sodium Chloride (Salt)	Sulfuric Acid (10-30%)
Pentane 2-4 Dimethyl	PREP 720 (2)	Sodium Cyanide	Tannic Acid
Petroleum	PRIMAL ASE-60	Sodium Hydroxide	Tartaric Acid
Phosphoric Acid-45%	Propane (Liquified) (LPG)	(20% Solution)	TERIC GN9
Pine Oil	Propylene Glycol	Sodium Hydroxide	Transformer Oil
Plating Solutions: Antimony	QUINTOZENE FLOWABLE	(50% Solution)	Transmission Fluid Type A
Plating Solutions: Arsenic	RAXIL C Flowable	Sodium Hypochlorite (to 5%)	Tung Oil
Plating Solutions: Brass	seed dressing	Sodium Hypochlorite (to 20%)	Turbine Oil
Plating Solutions: Bronze	ROVRAL AQUAFLO	Sodium Metaphosphate (1)	Turbo Oil
Plating Solutions: Cadmium	ROVRAL LIQUID	Sodium Nitrate	TWEEN 20
Plating Solutions: Copper	ROVRAL LIQUID S.D.	Sodium Peroxide	Varnish
Plating Solutions: Gold	Sal Ammoniac	Sodium Phosphate	Vegetable Oils
Plating Solutions: Indium	Salicylic Acid	Sodium Phosphate, Monobasic	Water
Plating Solutions: Iron	Sea Water	Sodium Phosphate, Tribasic	White Oil
Plating Solutions: Lead	SEMEVIN 500 P	Sodium Salts	Wine and Whiskey
Plating Solutions: Nickel	SENCOR 480 SC	Sodium Silicate	Wood Oil
Plating Solutions: Silver	Silicone Greases	Sodium Sulphate	X77
Plating Solutions: Tin	Silicone Oils	Sodium Sulfide	Xenon
Plating Solutions: Zinc	Silver Nitrate	Sodium Sulphite	Zinc Acetate
Polyvinyl Acetate Emulsion	Soap Solutions	Sodium Thiosulphate (Hypo)	Zinc Chloride
Potassium Acetate	Soda Ash (Sodium Carbonate)	Sorbitan Monolaurate	Zinc Salts
Potassium Chloride	Sodium Acetate	Polyoxethylene	Zinc Sulfate
Potassium Cupro Cyanide	Sodium Bicarbonate	Soybean Oil	
Potassium Cyanide Solutions	(Baking Soda)	SPIN FLOWABLE	
Potassium Dichromate	Sodium Bisulfate	Stannic Chloride	

(1) Test pump before use

(2) Wash pump after use

WARNING: Do not use with the following substances:
Hydrofluoric Acid • Jaguar • Morpholine • Tigrex

* CAPITAL LETTERS denote brand names. All brand name trademarks and registered trademarks are the property of their respective corporations.

**Westcott
Distribution**

184 W. 10th St., New York, NY 10014
(646) 486-3636 • Fax (212) 243-6070

GT100-PCG-1002A

GT 100 (red pump with Nitrile seal)

➤ **GT 200 (blue pump with EPDM seal)**

GT 200S (blue pump with Santoprene seal)

GT 300 (green pump with Viton seal)

Document date: **7 October 2002**

GT 200 Pump: General purpose chemicals

Listed substances are suitable for use with **GT 200** pumps. Before use, read and observe all warnings and cautions below, and in the *GoatThroat Instruction Manual*. To check for the most recently updated listings, please visit our web site at www.GoatThroat.com.

2,4-D Amine 500	Benzochloride	Citric Acid	Ethylacrylic Acid (2)
ACB - 30	Benzoic Acid	Coconut Oil	Ethylene Chlorohydrin
Acetaldehyde (2)	Benzyl Alcohol	Cod Liver Oil	Ethylene Diamine
Acetamide	Benzyl Benzoate	Coffee	Ethylene Glycol
Acetic Acid 10%	Black Sulphate Liquors	Coliche Liquors	Ethylmorpholine Stannous
Acetophenone	Borax (Sodium Borate)	Copper Acetate	Ferric Chloride
Acetyl Acetone	Bordeaux Mixture	Copper Chloride	Ferric Nitrate
Acetylene Tetrabromide	(Copper Sulfate Salt)	Copper Cyanide	Fluorolube
Acrylonitrile (Vinyl Cyanide) (1)	Boric Acid	Copper Sulfate 5% Solution	FOLICUR 250 EC
Aluminium Acetate	Brake Fluid (non petroleum)	Corn Oil	FOLIMAT 800
Aluminium Bromide	Brine	CORRECT 100 EC	Formaldehyde
Aluminium Chloride 20%	Bromine	Cottonseed Oil	Formalin
Aluminium Fluoride 20%	Butane (LPG) (1)	Cyclohexanol	Furfural (1)
Aluminium Nitrate	Butanol	Denatured Alcohol	Furfuraldehyde
Aluminium Sulfate 10%	Butter	Detergents	Furylcarbinol
Alums- NH3-Cr-K	Butyl Alcohol	Developing Fluids (photo)	Gallic Acid
Ammonium Carbonate 10%	Butyl Carbitol	Diacetone (1)	Gelatin
Ammonium Chloride (1)	Butyl Cellosolve	Diacetone Alcohol	Glucose
Ammonium Hydroxide	Butyl Cellosolve Adipate	Dibutyl Phthalate (2)	Glycerin
Ammonium Nitrate	Butyric Acid (2)	Dibutyl Sebacate (2)	Glycols
Ammonium Persulfate	Calcine Liquors	Diethylamine (2)	Green Sulfate Liquor
Ammonium Phosphate	Calcium Acetate	Diethylene Glycol	Hexyl Alcohol
(Di, Tri, & Mono)	Calcium Carbonate (Chalk)	Difluordibromomethane (2)	HFE Fluids [3M/Novoc] (1)
Ammonium Sulfate	Calcium Chloride (Brine)	Diisopropanolamine (2)	Hydrazine
Ammonium Sulphide	Calcium Hydroxide	Diisopropyl Ketone	Hydrobromic Acid
Amyl- Acetate (2)	Calcium Hypochlorite	Diisopropylamine	Hydrochloric Acid (25-30%)
Amyl -Alcohol	Calcium Nitrate	Dimethyl Formamide	Hydrochloric Acid (5-20%)
Amyl- Borate	Calcium Sulfide	Dimethyl Phthalate (2)	Hydrocyanic Acid
Anhydrous Ammonia	Calcium Thiosulphate	Dimethylisopropylamine	Hydrofluosilicic Acid
Anhydrous Hydrazine	Cane Sugar Liquors	Dioctyle Phthalate (2)	Hydrogen Sulfide (Wet) (Cold)
Anhydrous Hydrogen Fluoride	Caprioc Aldehyde (2)	DIPTEREX 500 SL	Hydrogen Sulfide (Wet) (Hot)
Aniline	Carbitol (2)	Distilled Water	Hydroquinone (2)
Aniline Hydrochloride 20%	Carbolic Acid	Epoxy Resins	Hypochlorous Acid 10%
Aniline Oil	Carbon Dioxide	Ethanol	Isobutyl Alcohol
Animal Fats	Carbon Monoxide	Ethanol 95%	Isobutyl-n-Butyrate
Aqua Regia	Carbonic Acid	Ethanolamine (1)	Isopropanol
Arsenic Acid	Castor Oil	Ethyl Acetate (2)	Isopropyl Acetate (2)
Automotive Brake Fluid	Cellosolve	Ethyl Acetoacetate (2)	Isopropyl Alcohol
Barium Chloride	Cellosolve Acetate	Ethyl Acrylate (2)	Isopropyl Amine (2)
Barium Hydroxide	Cellosolve Butyl	Ethyl Alcohol	Lactams- Amino Acids
Barium Sulfide	Celluguard	Ethyl Cellulosolve	Lactic Acid
BAYCOR 300	Chlorine	Ethyl Cellulose (2)	Lactones (2)
BAYFIDAN 250 EC	Chloroacetone	Ethyl Chloride	Lard
Beer	Chlorobromo-Methane (1)	Ethyl Chloroformate (1,2)	LE - MAT
Beet Sugar Liquors	Chrome Alum	Ethyl Oxalate	Lead Acetate
Benzine (1)	Chromic Acid 5%	Ethyl Silicate	Lead Nitrate

List continues on next page -->

(1) Test pump before use

(2) Wash pump after use

WARNING: Do not use with the following substances:
Hydrofluoric Acid • Jaguar • Morpholine • Tigrex

* CAPITAL LETTERS denote brand names. All brand name trademarks and registered trademarks are the property of their respective corporations.

**Westcott
Distribution**

184 W. 10th St., New York, NY 10014
(646) 486-3636 • Fax (212) 243-6070

GT200-PCG-1002A

GT 100 (red pump with Nitrile seal)

➤ **GT 200 (blue pump with EPDM seal)**

GT 200S (blue pump with Santoprene seal)

GT 300 (green pump with Viton seal)

Document date: **7 October 2002**

GT 200 Pump: General purpose chemicals

Listed substances are suitable for use with **GT 200** pumps. Before use, read and observe all warnings and cautions below, and in the *GoatThroat Instruction Manual*. To check for the most recently updated listings, please visit our web site at www.GoatThroat.com.

← *List continued from previous page*

Lead Sulfamate	Nickel Sulfate	Rapeseed Oil	Soybean Oil
Lime Bleach	NITOFOL	Sal Ammoniac	Stannic Chloride
Lime Sulpur	Nitric Acid 5-10% Solution	Salicylic Acid	Stannous Chloride
Linseed Oil	Nitrobenzene	SANTICIZER	Sucrose Solution
Lye	Nitromethane	Sea Water	Sulfuric Acid (10-30%)
Magnesium Chloride	N-Propyl Acetone	Silicone Greases	Sulfuric Acid (35-80%)
Magnesium Hydroxide	Olive Oil	Silicone Oils	Sulfuric Acid (85-90%)
Magnesium Salts	Oxalic Acid (Cold)	Silver Nitrate	Sulfuric Acid (90%+)
Magnesium Sulfate	Palmitic Acid	Soap Solutions	Sulfurous Acid
Maleic Acid	Perchloric Acid 72% (1)	Soda Ash (Sodium Carbonate)	Sulphur Hexafluoride
Malic Acid	Petroleum	Sodium Acetate	Tannic Acid
MCPA	Phenyl Hydrazine (1)	Sodium Bicarbonate	Tartaric Acid
MCPA 375 SALT	Phosphoric Acid	(Baking Soda)	Tera Bromoethane (1)
MCPA LVE 500	(to 40% Solution)	Sodium Bisulfate	Tertiary Butyl Alcohol
Mercuric Chloride (Dilute Solu.)	Phosphoric Acid	Sodium Bisulfite	Tetrabutyl Titanate
Mesityl Oxide (2)	(40-100% Solution)	Sodium Borate	Toluene (1)
Methalated Spirits	Phosphoric Acid Crude	Sodium Carbonate	Toluene Diisocyanate (2)
Methamidols	Phosphoric Acid-20%	Sodium Chloride (Salt)	TOUGH 450 EC
Methane	Phosphoric Acid-45%	Sodium Cyanide	Triacetin
Methanol	Phosphorous Trichloride	Sodium Hydroxide	Triaryl Phosphate
Methyl Acetate (2)	Acid (1)	(20% Solution)	Tributoxy Ethyl Phosphate
Methyl Acrylate	Picric Acid	Sodium Hydroxide	Tributyl Phosphate
Methyl Alcohol	Pinene	(50% Solution)	Tricresylphosphate
Methyl Bromide (1)	Plating Solutions: Chrome	Sodium Hydroxide	Triethanol Amine
Methyl Butyl Ketone	Polyvinyl Acetate Emulsion	(80% Solution)	Tri-isopropanolamine (2)
Methyl Cellulose (2)	Potassium Acetate	Sodium Hypochlorite (to 5%)	Trioctyl Phosphate
Methyl Chloride (1)	Potassium Chloride	Sodium Hypochlorite (to 20%)	Tripoly Phosphate
Methyl Ethyl Ketone	Potassium Cupro Cyanide	Sodium Metaphosphate (1)	Turpentine (1)
Methyl Mercaptan	Potassium Cyanide Solutions	Sodium Nitrate	Vegetable Oils
Methylacrylic Acid	Potassium Dichromate	Sodium Perborate	Vertrel Solvents (Dupont) (1)
Milk (2)	Potassium Hydroxide 60% (1)	Sodium Peroxide	Vinegar
Monoethanolamine (2)	Potassium Nitrate	Sodium Phosphate	Water
Monoethylene	Potassium Sulfate	Sodium Phosphate, Monobasic	Wine and Whiskey
Monovinyl Acetylene	Propyl Acetate (2)	Sodium Phosphate, Tribasic	Wood Oil
N-Butyl Acetate (2)	Propyl Alcohol	Sodium Silicate	Zeolites
N-Butyl Benzoate	Propyl Nitrate	Sodium Sulfide	Zinc Acetate
N-Butyl Butyrate	Propylene Glycol	Sodium Sulphate	Zinc Chloride
Nickel Acetate	P-Tertiary Butyl Catechol	Sodium Sulphite	Zinc Sulfate
Nickel Chloride	Pyridine Oil	Sodium Thiosulphate (Hypo)	

(1) Test pump before use

(2) Wash pump after use

WARNING: Do not use with the following substances:
Hydrofluoric Acid • Jaguar • Morpholine • Tigrex

* CAPITAL LETTERS denote brand names. All brand name trademarks and registered trademarks are the property of their respective corporations.

**Westcott
Distribution**

184 W. 10th St., New York, NY 10014
(646) 486-3636 • Fax (212) 243-6070

GT200-PCG-1002A

GT 100 (red pump with Nitrile seal)

GT 200 (blue pump with EPDM seal)

➤ **GT 200S (blue pump with Santoprene seal)**

GT 300 (green pump with Viton seal)

Document date: **7 October 2002**

GT 200S Pump: Liquids compatible with Santoprene drum seal

Listed substances are suitable for use with **GT 200S** pumps. Before use, read and observe all warnings and cautions below, and in the *GoatThroat Instruction Manual*. To check for the most recently updated listings, please visit our web site at www.GoatThroat.com.

Acetic Acid 10%	Chloroacetone	Isopropyl Myristate 98%	Sodium Chloride (Salt)
Acetic Anhydride (2)	Citric Acid	Lactic Acid	Sodium Hydroxide (20% Solution)
Acetone (1)	Copper Chloride	Linseed Oil	Sodium Hydroxide (50% Solution)
Acetylene (1)	Copper Sulfate 5% Solution	Magnesium Chloride	Sodium Hypochlorite (to 5%)
Aluminium Chloride 20%	Cottonseed Oil	Magnesium Hydroxide	Sodium Lauryl Sulfate (dodecyl sulfate 70%)
Aluminium Sulfate 10%	Cyclomethicone	Mercuric Chloride (Dilute Solu.)	Soybean Oil
Ammonium Chloride (1)	Dibutyl Phthalate (2)	Methyl Alcohol	Stannous Chloride
Ammonium Hydroxide	Diethyl Sebacate (1,2)	Methyl Butyl Ketone	Stearic Acid
Amyl-Acetate (2)	Dimethicone	Methyl Ethyl Ketone	Sulfuric Acid (35-80%)
Amyl-Alcohol	Diocetyl Phthalate (2)	Methyl Salicylate	Sulfuric Acid (85-90%)
Aniline	Distilled Water	Mineral Oil	Tannic Acid
Barium Hydroxide	Ethanol	Napthalene	Tartaric Acid
Beer	Ethanol 95%	Nitric Acid 5-10% Solution	Tergitol
Borax (Sodium Borate)	Ethyl Acetate (2)	Nitric Acid 20-50% Solution	Tetrahydrofuran (2)
Boric Acid	Ethyl Alcohol	Nitrobenzene	Thinners (1)
Butane (LPG) (1)	Ethyl Chloride	Oleic Acid	Triethanol Amine
Butyric Acid (2)	Ethylene Glycol	Palmitic Acid	Tung Oil
Calcium Chloride (Brine)	Ferric Chloride	Phenol (Carbolic Acid)	Water
Calcium Hydroxide	Formaldehyde	Pickling Solution	Wine and Whiskey
Calcium Hypochlorite	Glycerin	Potassium Dichromate	Zinc Chloride
Carbon Dioxide	Hydrazine	Potassium Hydroxide 60% (1)	
Carbon Monoxide	Hydrochloric Acid (35%)	Propylene Glycol	
Carbon Tetrachloride (1)	Hydrochloric Acid (5-20%)	Sea Water	
Castor Oil	Hydrocyanic Acid	Silicone Fluid	
Chlorine	Hydrogen Sulfide (Wet) (Cold)	Silicone Greases	
Chlorine (Wet)	Isopropyl Alcohol	Soap Solutions	

(1) Test pump before use

(2) Wash pump after use

WARNING: Do not use with the following substances:
Hydrofluoric Acid • Jaguar • Morpholine • Tigrex

* CAPITAL LETTERS denote brand names. All brand name trademarks and registered trademarks are the property of their respective corporations.

**Westcott
Distribution**

184 W. 10th St., New York, NY 10014
(646) 486-3636 • Fax (212) 243-6070

GT200S-PCG-1002A

GT 300 Pump: Aggressive chemicals & solvents

Listed substances are suitable for use with **GT 300** pumps. Before use, read and observe all warnings and cautions below, and in the *GoatThroat Instruction Manual*. To check for the most recently updated listings, please visit our web site at www.GoatThroat.com.

2,4-D Ester 800	Cresol (1)	Halowax Oil	Perchloroethylene
ACTICIDE 14	Cresylic Acid	HELOTHION EC	Phenol (Carbolic Acid)
ACTICIDE A2	Crude Oil	Hydrochloric Acid (25-30%)	Phenylbenzene
ACTRIL DS	Cumene	Hydrochloric Acid (35%)	Phorone
ALBAROL	Cyclohexane (1)	Hydrofluosilicic Acid	Phosphoric Acid
Alkazene (2)	Cyclohexanol	Hydrogen Peroxide (35%)	(to 20% Solution)
Alpha Cypermethryn	Decalin (Deklin)	Iodine (in Alcohol)	Phosphoric Acid
Amyl Naphthalene	Decane	Isopropyl Chloride	(to 40% Solution)
Aniline Dyes	Demeton-S-Methyl	KELTHANE	Phosphoric Acid
Aniline Hydrochloride 20%	DETER	KILVAL	(40-100% Solution)
Aniline Oil	DIAZINON 800	LARVIN LV	Phosphoric Acid Crude
BARREL	Dibenzyl Ether (2)	Lavender Oil	Pickling Solution
BAYLETON 125 EC	Dibenzyl Sebacate (2)	LEBAYCID	Picric Acid
Benzene (1)	Dibromomethyl Benzene	Linoleic Acid	Pinene
Benzenesulfonic Acid 10%	Dichloro Butane	Linseed Oil	Propylene
Benzyl Alcohol	Dichlorobenzene	MALDISON 500	Prothiofos
Benzyl Benzoate	Diesel Fuel	Maleic Anhydride	Pyroligneous Acid (2)
Benzyl Chloride (1)	Di-ester Synthetic Lubricants	MARLIN	Pyrolubo
Bromine	Diethyl Sebacate (1,2)	METASYSTOX (2)	ROGOR 400
Bromine- Water (1)	Diisooctyl Sebacate (2)	Methalacrylic Acid (2)	Silicate Esters
Bromobenzene (1)	Dipentene	Methyl Bromide (1)	Sodium Hypochlorite (to 5%)
Bromochloro Trifluoroethane	Diphenyl	Methyl Chloroformate	Sodium Hypochlorite (to 20%)
BUCTRIL MA	Diphenyl Oxide (1)	Methyl D-Bromide	Stearic Acid
BUCTRIL 200	Dry Cleaning Fluids	Methyl Oleate	Sulfur Chloride
BULLDOCK 25 EC	ENDOSULFAN	Methylcyclopentane	Sulfuric Acid (90%+)
BULLDOCK 8 UL	ENDOSULFAN ULV	Methylene Chloride (1)	Sulphur Liquors
Butadiene	Ethyl Benzene (1)	Methyl Dichloride (1)	SUPRACIDE
Butyl Acetyl Rincinoleate	Ethyl Benzoate	Monobromobenzene (1)	Terpineol
Butyl Oleate	Ethyl Bromide	Monochlorobenzene (1)	Tertiary Butyl Alcohol
Butyl Stearate	Ethyl Cellulose (2)	Monomethyl Aniline	Tetrabutyl Titanate
Calcium Hypochlorite	Ethyl Chlorocarbonate	Naptha	Tetrachloroethylene (1)
Carbamate	Ethyl Formate	Napthalene	Tetrachloroethane (1)
Carbolic Acid	Ethyl Pentochlorobenzene (1)	Napthenic Acid	Tetraethyl Lead
Carbon Bisulfide (1)	Ethylene Chloride (2)	NEMACUR 400 EC	Tetraline (1)
Carbon Disulfide	Ethylene Dibromide (1)	Neville Acid	Titanium Tetrachloride (1)
Carbon Tetrachloride (1)	Ethylene Dichloride	Nitric Acid 20-50% Solution	TOKUTHION
Cellosolve Acetate	Fenamiphos	Nitric Acid 60-70% Solution	Toluene (1)
CHLORDANE	FOLIDOL M500	Nitrobenzene	TOTRIL
Chlorextol	Formaldehyde	O-Chlorophenol	Trichloroethylene (1)
Chlorinated Salt Brine	FUEL DOCTOR	Octachlorotoluene (1)	TRIDAN
Chlorinated Solvents	Furfural Alcohol	OFTANOL TURF	Trinitrol Toluene (2)
Chlorine Chlorine (Wet)	Fumaric Acid	Oleic Acid	Turpentine (1)
Chlorobenzene (Mono) (1)	Gasoline Leaded	Orthochloro Ethyl Benzene	White Pine Oil
Chlorobutadiene (1)	Glacial Acetic Acid (2)	Parathion Ethyl Methyl	Xylene Xylol
Chlorododecane (1)	Glaubers Salt	P-Cymene	
Chloroform (1)	GUSATHION A LIQUID	P-Dichlorobenzene	
Chlorotoluene (1)	Halothane	Perchloric Acid 72% (1)	

(1) Test pump before use

(2) Wash pump after use

WARNING: Do not use with the following substances:
Hydrofluoric Acid • Jaguar • Morpholine • Tigrex

* CAPITAL LETTERS denote brand names. All brand name trademarks and registered trademarks are the property of their respective corporations.

**Westcott
Distribution**

184 W. 10th St., New York, NY 10014
(646) 486-3636 • Fax (212) 243-6070

GT300-PCG-1002A